

I nversand Company

ORIGINAL DEVELOPERS OF MANGANESE GREENSAND AND GREENSANDPLUS

P.O. BOX 650
CLAYTON, NEW JERSEY 08312-0650
856-881-2345
FAX 856-881-6859
E-mail: sales@inversand.com

PROCEDURE FOR COLLECTING A REPRESENTATIVE FILTER MEDIA CORE SAMPLE

To properly sample filter media, the media must be thoroughly backwashed. After backwashing the media, drain the filter completely and remove the manway cover.

Using a 1 ¼" or 1 ½" diameter by 4' to 6' long (depending on the bed depth and amount of freeboard) piece of thin wall tubing, insert the tube approximately six inches into the media with a twisting motion. Empty the media into a clean bucket by tapping the side of the tube. Repeat this procedure, being sure to sample the same hole, at six-inch increments until the entire media bed has been sampled and the gravel or gravel retaining screen, if such has been installed in the unit, has been intersected.

The composited sample should then be thoroughly mixed to obtain a representative sample and no less than one quart of the material forwarded to us for laboratory evaluation. If one core sample does not yield a full quart, a second core sample should be obtained and mixed together with the first so that a full quart is available for analysis.

CAUTION: *Be sure to sample only the filtering media. DO NOT force the sample tube into the sub-fill or the underdrain.*

Place a minimum of one quart of the sampled media into a waterproof container

Mud balls or foreign material on or in the media should be included in the core sample. A separate sample of any foreign material or mud balls should be sent along with the core samples.

Note the depth of the filter media (by inserting a ruler into the sample hole) and the general condition of the bed surface. Note observations such as the media level, media mounding, and fissures (channels) on the media surface.

NOTE: *Prior to sending in a sample to be analyzed, please contact our Sales Department at 856-881-2345 and request a quotation for this service. Our Sales Department will request a Purchase Order and will provide you with an Inversand Sales Order number for tracking purposes. We will also provide a form requesting additional information on your system that would be very helpful in generating a report on the condition of your media.*

Include with sample: Person, Company, Address, Phone Number
Type of Media sample (Greensand, Anthracite, etc.)
Date sampled
Reason for sample (low capacity, poor quality, etc.)
Purchase Order Number

Forward sample to: INVERSAND COMPANY
Attn: Sales Department/Lab
P.O. Box 650
Clayton, NJ 08312

**INSTRUCTIONS FOR INSPECTION OF THE UNITS
AND SAMPLING OF THE GREENSAND OR
GREENSAND/ANTHRACITE FILTER MEDIA**

1. General

- a. Backwash, drain, open unit, and sample per attached instructions.
- b. Is the bed completely level (no mounding around edges)? Yes No
- c. Bed depth _____ inches; Original Bed Depth _____ inches
- d. Examine the surface of bed.
- e. Is it dirty? Yes No
- f. Are mudballs present? Yes No
- g. Are greensand fines visible on top dual media bed? Yes No Not applicable (sand/anthracite filter media bed)
- h. No. of units _____ Diameter of filter(s) _____

Comments (describe conditions found):

2. Operating Conditions

- a. Plant flow rate _____ gpm _____ gpd
- b. Run length _____ hrs. _____ gals.
- c. Pressure differential at beginning of run _____ psi
- d. Pressure differential at end of run _____ psi
- e. Raw water, iron _____ mg/L; Manganese _____ mg/L
- f. Is process CR or IR?
- g. Is chlorine fed? Yes No lb/day _____
- h. Pre-feed, post-feed, or both? Pre – Post – both
- i. Is KMnO₄ fed? Yes No lb/day _____
- j. Pre-pH correction? Yes No
- k. If feeding both Cl₂ and KMnO₄ How far is Cl₂ fed upstream of KMnO₄ injection point? _____ ft.
- l. Any iron or manganese breakthrough at end of run? Yes No
- m. Is filter effluent clear at the end of run? Yes No
- n. Backwash rate _____ gpm Time _____ minutes
- o. Air wash frequency _____
- p. Age of filter media _____ years

3. Additional Services

If you wish to have your water analysed please send 1-qt samples of your raw and treated water for analysis. Include a separate 2-oz bottle of both raw and treated water for an iron analysis.

4. Company Information/Bill to

Name: _____
Street: _____
City: _____
State: _____
Zip code: _____
Phone: _____
Fax: _____
Email: _____

PLEASE ENTER YOUR PURCHASE ORDER NUMBER BELOW. THE SAMPLES WILL NOT BE ANALYSED UNTIL AFTER A PO NUMBER IS PROVIDED.

Purchase Order #: _____

Note: Please fill out this form and send it in with your sample.